




Call (678) 394-8009 for inquiries or instructions or info@cooldaddys.com

## COOL DADDY'S MACHINE INSTRUCTIONS



**CAUTION:** Machines are heavy; we do not recommend moving once we deliver them. If you do need to move be sure to move with 2 people and always place on secure table or cart. You are responsible for any damage to the machine as a result of moving and or falls.

Most common misuse of our machines happen when machines are placed on the same outlet or circuit as another appliance. Residential outlets have a maximum capacity of 20 amps per circuit. Our machine pull 15 amps. It is important that you do not place the machine on the same outlet OR circuit as another electrical item. Customers are responsible for any power surges that damage the machine.

**Freezing of the liquid takes approx. 2-3 hours** from the time you turn the machine on. It is best to leave machine running as far in advance of your event start time as possible in order to allow for well-frozen beverages. Machine should be placed indoors 75°F or lower for initial 2-3 hours of freezing.

To turn the machine off or on, press the **Main Power Button**

The **Auger Buttons** control whether or not the auger inside the machine is turning. Whenever you are using the machine the augers should **Always be on**.

The **Freeze Buttons** allow you to choose the level at which you want each side of the machine to operate. There are 3 options: ice, chill, and off. In order to freeze product, set each side to **ICE**. If you notice during your event that the mix is becoming too thick, you can switch each side independently to the chill setting as needed on each side until the drinks are thinner again. It is also important to note on the double machine that one side will freeze faster than the other side. This is normal and you can expect this.

**Look on the label on your bottle of mix to see if it 4:1 or 5:1 ratio:**

To make a 4:1 mix, add 2 gallons of water and one bottle of mix to each side of the machine.  
To make a 5:1 mix, add 2.5 gallons of water and one bottle of mix to each side of the machine.

**If adding liquor to your mix,** follow this basis recipe:

mix first, 2 gallons water & 1 bottle flavor mix. Once frozen, then add 1 liter of COLD liquor of your choice.

**Frozen wines:**

Simply add your choice of wine to the machine and freeze. One bowl will hold 2 1/2 gallons of unfrozen liquid, so plan accordingly..

Your rental includes the following items: a double or single bowl Bunn II machine, mixing jugs, black cart & power cord. Please be sure that all of these items are returned with your machine at the scheduled pickup time. If any of these items are lost or damaged during your use you will be charged the following replacement costs.

- Machine Circuit panel/fuse (due to power surge): \$250
- Clear bowl (holding chamber for mix): \$200 each
- Cart: \$125
- Power Cord: \$25
- Mixing Jugs: \$20 each

**To prepare your machine for pickup** run warm water through the hoppers (clear chambers) a few times to get any remaining drink mix out. Wipe down the exterior with a warm wet cloth and wash out your drip tray. You do not need to take apart the machine. We will do a thorough cleaning when we get it back. A \$25 cleaning fee applies to machines that have not been cleaned or have remaining mix in the chambers.